



# PnP USB – 485 Converter Stick

## Driver Installation Manual for Windows 2000 and Windows XP® (Vista)

Insert the PnP USB – 485 Converter Stick into an available USB Port on your PC.

(The yellow LED will light up on the Converter Stick)



Next the USB-serial-port is created. Press **Next**.



Press **Continue Anyway**.




The USB-485 driver is now installed and the USB-485 can be used. Press **Finish**.




## Changing the COM Port number

By installing the driver, the USB – 485 is inserted into the device manager under “Universal Serial Bus controllers” and under “Ports (COM and LPT)”.




To change the settings of the USB serial port, highlight the port as shown, click on the **right mouse button** and choose **properties**.

Press **Port Settings**.



Press **Advanced**.





You can change now the COM connection number to the desired value.

**Attention!!!**

The new COM- connection number may not be assigned yet.

